

MEASURING FOR WINDSCREEN

Custom windscreens from Team Fitz are available in any size and are made specifically to fit to the size of your school's fences. To properly measure for a windscreen:



1. Start with the horizontal measurement. Measure fence from tension bar to tension bar (just inside vertical post). Do not include end posts in the measurement. Windscreens should only cover the fence mesh. Measure doors, gates and transoms (space above a door on tennis court) in the same way.
2. Next measure for height. The height should be measured from the bottom of the top rail to the top of the bottom rail. Keep in mind, there is no need to cover the full height of the fence. If you decide you would like the entire fence covered, we recommend reducing the total height by 6 inches. This will leave space at the bottom of the fence to allow trimmers and mowers to pass without harming your windscreen.
3. Include feet and inches. Exact measurements are necessary—do not guess or round off dimensions.
4. For best results, put together a rough sketch of your fence with the measurements included to help us fully understand the layout.

Tip to Reduce Cost

It is not always necessary to cover the full fence height. Often you can achieve a significant visual impact with a band of windscreen running along the middle or top half of a fence.

